


ASSEMBLY INSTRUCTION READ CAREFULLY




Model No.	Inside Dimensions	Outside Dimensions	Recommended Concrete Pad Dimensions
200D-Series	30"W x 46"L x 40"H	33 3/4"W x 49 1/8"L x 43 1/4"H	44"W x 60"L x 6" Thick
300D-Series	48"W x 78"L x 44"H	51 3/4"W x 81 1/8"L x 47 1/4"H	62"W x 92"L x 6" Thick
300TD-Series	48"W x 78"L x 50"H	51 3/4"W x 81 1/8"L x 53 1/4"H	62"W x 92"L x 6" Thick

1. Center a "6" thick concrete base around installed BFP.
 - A. Place expansion material around riser pipes and place conduit for electrical power before placing concrete. **CONCRETE SHOULD BE FINISHED ABSOLUTELY LEVEL, FLAT AND SMOOTH.** Allow concrete to cure.
 - B. Mark concrete with outside dimensions of enclosure. (Center around BFP).

2. Using four (4) hexhead screws for each section, assemble both "A-B" sections thru holes provided and set on marked concrete base (FIG 2).

3. Set "D" (roof) panel on "A-B" sections and using four (4) hexhead screws fasten thru holes provided.
4. A. Using one (1) hexhead screw attach **Outside Corner SS Anchoring Brackets** to "A-B" sections. Fasten bracket to concrete using one wedge anchor for each bracket (FIG 1A). Use the masonry bit provided. Drill into the concrete 3" deep. Insert wedge anchor, strike the wedge anchor until it is secure. Use the washer and nut provided to secure the anchor bracket.
 B. Square the "A-B" corners. Align the "B" panels so that they form a straight line. Using one (1) hexhead screw and one (1) wedge anchor for each bracket attach **Inside Aluminum Anchoring Brackets** to "B" panels and concrete (FIG 1B).
 C. Insert **Inside Roof Clips** in "D" (roof) panel. Using one (1) hexhead screw in each clip attach clip to "B" (side) panel (FIG 1C).



5. Set "C" panels and lock in place. (Solid "C" panel to be **DOOR** panel).
6. Provide ground-fault interrupter device in electrical circuit according to applicable codes. Install heater as per manufacturer's instructions and governing local and national codes.
7. For maximum protection it is suggested that the area between the bottom of the enclosure and the concrete base be caulked with the exception of the "C" panels. **DO NOT CAULK THE BOTTOM OF THE "C" DOOR PANELS.**

REMOVE MASKING FILM IMMEDIATELY
AFTER INSTALLATION

SAFE-T-COVER
 1-800-245-6333
 HCF200D-2

Model No. 200D Series
Model No. 300D Series
Model No. 300TD Series

Contents

- 2- "A" (end) Panels**
- 4- "B" (side) Panels**
- 1- "C" (drain door) Panel**
- 1- "C" (solid access) Panel**
- 1- "D" (roof) Panel**
- 4- Outside Corner SS Anchoring Brackets (1 1/2" x 1 1/2")**
- 4- Inside Aluminum Anchoring Brackets (3" x 3")**
- 4- Inside Roof Clips**
- 8- Wedge Anchors**
- 26- Screws**
- 1- Masonry Bit**
- 1- Magnetic Chuck**

TOOLS NEEDED

Hammer

Drill

7/16" Wrench

SAFE-T-COVER
1-800-245-6333
HCF200D-3